



RECOMMENDED FABRICS


- 100% Cotton
- 100% Polyester
- Cotton/Poly Blends

Due to the combination of fabrics, weaves, coatings and dyes used in the textile industry, we recommend testing the application before production.

APPLICATION

 35 seconds

 285° F

 Firm

 Hot

RECOMMENDED PRINTERS

All Ink and Bubble Jet Printers.
NOT recommended for use with generic refill inks, use OEM only.

Inkjet Opaque - For Darks

Our Opaque Transfer papers are designed to provide a soft hand with excellent durability and washability. Designed for application on dark fabrics while providing vibrant colours.

PRINTING

- Do not mirror your image
- Remove paper backing (hold image side of transfer towards you, make a small crease on the corner. Flip the transfer over and fold the crease in opposite direction, gently tear paper backing along crease to separate transfer from paper backing. Do not tear the transfer.
- After tearing the corner, separate the layers and gently peel the transfer just past the image.
- Do not remove completely from paper backing; let the transfer lay down onto the paper backing. Trim around your image and then peel entire transfer away from paper backing.

APPLICATION

1. Preheat your garment for 5 to 10 seconds
2. Position your transfer image side up, cover with Kraft Paper cover sheet
3. Heat apply for 35 seconds with a low-medium pressure
4. Peel Kraft Paper hot

CARE

- Wash garment separately (first time only)
- Turn inside out
- Machine wash warm or cold, using mild detergent
- Do not use bleach
- Tumble dry on low
- Do not iron directly onto transfer
- If bleeding occurs, re-wash immediately



All technical information and recommendations are based on tests we believe to be reliable. However, we cannot guarantee performance conditions not under manufacturer's control. Before using, we recommend testing to determine suitability of the product for its intended use. The user assumes all risk and liability whatsoever in connection with the use of this product.